


Exploded View / Parts List — POP-IT® Tool PHD0535

KEY NO.	ITEM DESCRIPTION	NO. REQ'D.
1	BODY	1
2	RISER	1
3	OUTSIDE TOE	2
4	DRIVE SCREW	1
5	TOP PLATE	1
6	BEARING FLANGE	1
7	THRUST BEARING	1
8	FLAT WASHER	1
9	WAVE DISC SPRING	1
10	SHAFT COLLAR	1
11	OUTSIDE TOE CAP SCREW	6
12	SPRING LOCKWASHER	6
13	TOP PLATE CAP SCREW	6
14	TOP PLATE CAP SCREW LOCK NUT	6
15	HANDLE ASSEMBLY	1
16	RATCHET SET SCREW	2
(not shown)	RATCHET	1



GEARENCH

P.O. Box 192 • 4450 S. Hwy. 6
Clifton, Texas 76634
(254) 675-8651 • fax (254) 675-6100
www.GEARENCH.com
©2009 GEARENCH, All Rights Reserved